

## Dual fuel Gas-Oil/Gas burner

| MODEL       | TYPE    |
|-------------|---------|
| GI/EMME 600 | 497 T80 |




## TECHNICAL FEATURES

|   |   |
|---|---|
| Thermal power                                     | 174/348 ÷ 697 kW - 150.000/300.000 ÷ 600.000 kcal/h   |
| Fuels   | Oil, max. viscosity at 20°C: 6mm <sup>2</sup> /s (1.5°E) natural gas with Pci 8600 kcal/m <sup>3</sup><br>Lpg with Pci 22.200 kcal/m <sup>3</sup> |
| Minimum gas pressure (measured at the test-point) | Maximum capacity requires 13 mbar with natural gas, 15 mbar with LPG. Combustion chamber at 0 mbar.   |
| Maximum gas pressure                              | 150 mbar  |
| Electrical supply                                 | Three-phase 380 V +10% -15% ~ 60 Hz with neutral  |
| Motor   | 1.9 A/380V  |
| Pump-capacitor motor                              | 1A / 220 V - 6.3 µF   |
| Ignition transformer                              | Primary: 1.8A / 220 V - Secondary: 30 mA / 1x8 kV   |
| Pump  | Output 80 kg/h at 12 bar - max pressure 15 bar  |
| Operation   | Two stages gas  |

The burner conforms to IP 40 level of insulation as per CEI/70.1

**Fig. 1**



### KEY TO LAY-OUT



- 1 - Oil valve 1° stage
- 2 - Oil valve 2° stage
- 3 - Safety oil valve
- 4 - Oil supply port
- 5 - Oil return port
- 6 - Pressure regulator at the pump
- 7 - Air damper motor
- 8 - Pressure gauge port (G 1/8)
- 9 - Vacuum gauge port (G 1/8)
- 10 - Terminal board
- 11 - Reset push-button of the motor overload relay
- 12 - Cable gland
- 13 - UV photocell
- 14 - Oil motor capacitor
- 15 - Oil-gas selector switch
- 16 - Control-box reset button
- 17 - Air pressure-switch
- 18 - Gas pressure socket to sleeve

### EQUIPMENT


| Quantity | Burner accessories         |
|----------|----------------------------|
| 1        | Gas-train's gasket         |
| 8        | Screws                     |
| 1        | Insulating screen          |
| 3        | Seal                       |
| 2        | Oil hoses                  |
| 4        | Connectors                 |
| 4        | Gaskets                    |
| 1        | Lpg transf. kit            |
| 2        | Oil nozzles                |
| 1        | Flange                     |
| 1        | Pipe fitting for gas train |

DIMENSIONS

Boiler front-plate drilling



Burner




\* Extension that you can obtain with special extended head (to be requested separately).

WORKING RANGE


PRESSURE IN THE COMBUSTION CHAMBER - 2<sup>nd</sup> STAGE OUTPUT

Min output at 1<sup>st</sup> stage 174 kW - 15 Kg/h




MINIMUM GAS PRESSURE - 2<sup>nd</sup> STAGE OUTPUT

Pressure: measured at the test point with combustion chamber at 0 mbar.



## FIXING TO THE BOILER




In order to divide the combustion head from the rest of the burner, you have to:

- remove the connection (1) from the two valves;
- remove the 4 screws (2 - 3);
- slide the burner body (A) along the rails (4);
- mount the group (B) to the boiler's plate (6) interposing gasket (5).


Mount the group (A) to the boiler front. Fit the nozzles and regulate the combustion head (as specified below).

## GAS SUPPLY LINE




- |                         |                                  |
|-------------------------|----------------------------------|
| 1 - Gas supply pipe     | 7 - Min. gas pressure switch     |
| 2 - Manual valve        | 8 - Gas safety shut off valve    |
| 3 - Isolator joint      | 9 - 1° stage gas shut off valve  |
| 4 - Filter              | 10 - 2° stage gas shut off valve |
| 5 - Pressure governor   | 11 - Burner                      |
| 6 - Pressure test-point | 12 - Gas leak control device     |

OIL SUPPLY



| H<br>m | L m  |       |
|--------|------|-------|
|        | Øi 8 | Øi 10 |
| 0.5    | 4    | 10    |
| 1      | 8    | 20    |
| 1.5    | 12   | 30    |
| 2      | 16   | 40    |
| 2.5    | 20   | 50    |




| H<br>m | L m   |       |
|--------|-------|-------|
|        | Øi 10 | Øi 12 |
| 0      | 40    | 100   |
| 0.5    | 36    | 90    |
| 1      | 32    | 80    |
| 2      | 24    | 58    |
| 3      | 15    | 36    |
| 3.5    | 10    | 25    |

**Please note:**  
all oil lines must be airtight.  
We suggest copper-piping. Level as the suction pipe, then a none return valve is not required and the section-pipe can be disconnected without causing any problems.

**H** = Margin;                      **L** = Inlet-pipe's length, including the vertical line.  
The copper pipes with diameter 10 and 12, shown in the schemes, can be replaced with 3/8 and 1/2 steel pipes, commercial gas without welding.

BURNER ELECTRICAL WIRING

(carried out in the factory)



S7598

SELECTOR SWITCH

|         | OIL O GAS |  |   |
|---------|-----------|--|---|
|         |           |  |   |
| 3 - 4   | X         |  |   |
| 5 - 6   | X         |  |   |
| 7 - 8   | X         |  |   |
| 9 - 10  |           |  | X |
| 11 - 12 |           |  | X |
| 13 - 14 |           |  | X |
| 15 - 16 | X         |  |   |


S7562

KEY TO LAY-OUT

- C: Pump motor capacitor
- CMV: Contact-maker
- CO: Selector switch
- MB: Burner terminal strip
- MP: Pump motor
- MV: Fan motor
- PA: Air pressure switch
- RT: Thermal relay
- SM: Servo-motor
- TA: Ignition transformer
- TB: Burner earth
- UV: Probe U.V.
- V1: 1° stage valve
- V2: 2° stage valve
- VS: Oil safety valve

## ELECTRICAL CONNECTIONS TO THE WIRING TERMINAL BLOCK

(to be carried out by the installer)



### KEY TO LAYOUT

**MB** - Burner terminal strip  
**MR** - Gas train terminal strip  
**TS** - Safety remote control system  
**TL** - Limit control system  
**T2** - 2° stage remote control system  
**PG** - Min. gas pressure switch

**V1** - 1° stage gas shut off valve  
**V2** - 2° stage gas shut off valve  
**VS** - Gas safety shut off valve  
**S** - Remote lock signal  
**PC** - Check pressure switch  
**TB** - Burner earth

### NOTICE


- The electric wiring carried out by the installer must be in compliance with the rules in force in the country.
- Leads minimal section 1.5 mm<sup>2</sup>.
- Burners with non-stop operation: for safety reasons, this type of burner must be stopped every 24 hours of operation, by means of an hours-counter to be connected in series with the adjustment devices.
- The flame modulation is obtainable through the 2° stage remote control system (T2). Connected to the terminals 9-10.



---

## FIXING OF THE ELECTRICAL WIRES

All the electrical wires, which are to be connected into the terminal rail 10 (fig. 1) should pass through the cable glands hubs 12 (fig. 1), accordingly the scheme below.



S7600

- |                           |                                   |
|---------------------------|-----------------------------------|
| 1 - Supply                | : gland Pg 21                     |
| 2 - Regulation thermostat | : gland Pg 13.5                   |
| 3 - Safety thermostat     | : gland Pg 13.5                   |
| 4 - 2° stage thermostat   | : gland Pg 13.5                   |
| 5 - GAS TRAIN             | : gland Pg 13.5 - for sheath ø 13 |

To guarantee the IP 40 protection level, in accordance to CEI 70.1, seal the glands that are not used.

### NOTES

- Do not exchange "Neutral" with "Phase" (avoid a plug/socket connection).
  - Make a good earth connection.
- Verify that the burner will lockout by firing the burner and obscuring the UV cell.

### ATTENTION

When you close the burner on the two guide rail, all the slack should be pulled out the high voltage-cable.

This burner is in accordance to the CEE law n.76/889, D.M. 9/10/1980, for protection against radio-noises.

## COMBUSTION HEAD ADJUSTMENT


Adjustments can be made to the burner, when it is still open for installation (see page 3, fixing to the boiler).

### NOZZLE'S CHOICE

Spray angle:

- usually, 60°
- for narrow combustion chambers: 45°

#### Position of the ignition electrodes



| Pump pressure | Nozzle |      |      |      |               |
|---------------|--------|------|------|------|---------------|
|               | 1°     |      | 2°   |      | 1°+2°<br>kg/h |
| bar           | GPH    | kg/h | GPH  | kg/h |               |
| 11            | 4.00   | 15.0 | 4.00 | 15.0 | 30.0          |
| 10            | 4.50   | 16.4 | 4.50 | 16.4 | 32.8          |
| 12            | 4.50   | 18.0 | 4.50 | 18.0 | 36.0          |
| 10            | 5.00   | 18.2 | 5.00 | 18.2 | 36.4          |
| 12            | 5.00   | 20.4 | 5.00 | 20.4 | 40.8          |
| 10            | 5.50   | 19.7 | 5.50 | 19.7 | 39.4          |
| 12            | 5.50   | 22.0 | 5.50 | 22.0 | 44.0          |
| 10            | 6.00   | 22.0 | 6.00 | 22.0 | 44.0          |
| 12            | 6.00   | 24.0 | 6.00 | 24.0 | 48.0          |
| 10            | 6.50   | 24.0 | 6.50 | 24.0 | 48.0          |
| 12            | 6.50   | 27.0 | 6.50 | 27.0 | 54.0          |
| 10            | 7.00   | 25.5 | 7.00 | 25.5 | 51.0          |
| 12            | 7.00   | 28.4 | 7.00 | 28.4 | 56.8          |
| 11            | 7.50   | 30.0 | 7.50 | 30.0 | 60            |


### SETTING OF GAS DISTRIBUTOR

The burner leaves the factory setted for burning natural gas (see the drawing on the right):



- Each hole (F) completely opened.
- For operation up to 400.000 kca/h, fit 2 nozzles with 4 mm diameter outlets to holes (F) (1 and 2). The fitting is suggested to get better combustion performance.

**To burn LPG fit the kit as detailed below:**

- Fit 6 nozzles with  $\varnothing$  4 mm diameter outlets to holes (F).



Loosen the two screws (1), move the elbow (2) so that the rear part (3) coincides to the desired set-point (4). Tighten the screws (1).



## ADJUSTMENT OF THE AIR DAMPER MOTOR

### STOP - Blue lever

This lever leaves the factory vertically positioned and corresponds to the complete closing of the air damper.

A partial opening of the air damper might be obtained by moving leftwards this lever (+ on the label).


The new position the air damper is detectable when the burner is off. Do not overcome the position of the orange lever for the 1<sup>st</sup> stage.

### 1st STAGE - Orange lever

The orange lever controls the air damper position for the first flame, it is adjustable both for opening and closing.

### 2nd STAGE - Red and black levers


The red lever controls the air damper position for the second flame, it is adjustable both for closing and opening. The black lever controls the opening of the second oil valve and it must always - for a bit - the red lever, but never the orange one.



## BURNER START-UP CYCLE

Venting the gas supply.

This is done by removing the screw from the gas pressure switch, or the pressure test point.




S7577

## AIR PRESSURE SWITCH (17 Fig.1)

Adjust the air pressure switch after adjustment of all the other parts of the burner, with air pressure switch setted at beginning of the scale.

When the burner works (1<sup>st</sup> stage) increase the regulating pressure, turning the handle slowly in the clockwise till the burner is locked out.

Then turn back of 1 mbar and repeat the burner's starting, in order to verify the good work; if you have a lock out, turn back once again of 0.5 mbar.



S7550

## PUMP'S FIRING

In case of drop-plant with supply from the tank's bottom, back off the plug at the vacuumeter-joint 9) (fig. 1), till the leaking of fuel.

In the other two situations, start up the burner, bleed the air of manometer-joint 8) P (fig. 1); if you have a lock-out, repeat the cycle.

### ATTENTION

Before starting up the burner, check that the return pipe has no occlusions. Any occlusions will cause the break of the pump-sealing organ.

## WORK WITH OIL

At the first ignition, when there is the passage from the first to the second flame, there is a strong decrease of fuel-pressure owing to the filling of second nozzle's pipe. This decrease can cause the burn-out of the burner.

## COMBUSTION CHECKS

### CO<sub>2</sub>

It is better to set the burner with CO<sub>2</sub> not higher than 10% (gas with Pci 8600 kcal/m<sup>3</sup>).

So you avoid that a little unsettling (for example draft variation) causes combustion with few air and with the production of CO.

### CO

It must be not higher than 0.1% (thousand parts for million) in accordance to UNI-CIG 8042 norme.


## CURRENT TO THE UV PHOTOCELL

Min. value for a good work: 15  $\mu$ A.


If the value is lower, it can depends on:

- worked out photocell.
- low current (lower than 187V)
- bad regulation of the burner.

In order to measure the current, use a microammeter of 100  $\mu$ A c.c., connected to the photocell, as in the scheme, with a capacitor of 100  $\mu$ F - 10V c.c. at the same level of the instrument.



## BURNER STARTING UP PROGRAMME



If during the work the flame burns off, there is a lock out within 1 second.

---

## **BURNER STARTING DIFFICULTIES AND THEIR CAUSES (GAS)**

The electrical equipment is fitted with a disk which rotates during the start-up program and can be seen through the release inspection window. When the burner does not start or stops because of a fault, the symbol which appears in the inspection window indicates the type of interruption fault.

### **◀ THE EQUIPMENT DOES NOT START WHEN THE THERMOSTATS CLOSE**

- There is no gas.
- The min. gas pressure switch does not close the contact: it is incorrectly adjusted.
- The air pressure switch is set in operating position.
- The equipment fuse has blown.
- The cam pos. 1 selector switch does not close the circuit, equipment terminals 11 and 8.

### **▲ HALT AFTER START-UP**

- The cam pos. 2 selector switch does not close the circuit, equipment terminals 9 and 8.

### **P LOCK HALT**

The air pressure switch does not effect a selection because of:

- a fault contact;
- insufficient air pressure.

### **■ LOCK HALT**

Malfunctions of the flame detection circuit:

- photo-sensitive cell exhausted;
- fault internal amplifier.

### **▼ PRE-VENTILATION HALT**

- The cam pos. 3 selector switch does not close the circuit, equipment terminals 10 and 8.

### **1 LOCK HALT, no flame signal:**

- .....
- photo-sensitive cell connection to the equipment is interrupted;
- insufficient electrical detection current (min. 70  $\mu$ A).

### **I LOCK HALT IN OPERATION BECAUSE OF:**

- no flame signal;
- no air pressure.

### **N.B.:**

- If the lock halt takes place between start and pre-start-up without a fault symbol appearing, the fault is usually flame simulation.
- The burner continues repeating the start-up cycle without the lock taking place:
  - a) there is oscillation of the min. gas pressure switch caused by adjustment very close to the mains pressure, so that the drop in pressure which occurs at burner start-up is sufficient to trigger action and this cause a new start-up cycle.



---

# RIELLO

RIELLO S.p.A.  
Via degli Alpini 1  
I - 37045 Legnago (VR)  
Tel.: +39.0442.630111 Fax: +39.0442.630375