

## **GB** Dual fuel light oil/ gas burners

Modulating operation



CODE	MODEL	TYPE
20051416	RLS 1000/EV MX	1311 T2
20047475	RLS 1200/EV MX	1312 T2



**Translation of the original instructions**

<b>1</b>	<b>Declarations .....</b>	<b>3</b>
<b>2</b>	<b>Information and general warnings.....</b>	<b>4</b>
2.1	Information about the instruction manual .....	4
2.1.1	Introduction.....	4
2.1.2	General dangers.....	4
2.1.3	Other symbols .....	4
2.1.4	Delivery of the system and the instruction manual .....	5
2.2	Guarantee and responsibility .....	5
<b>3</b>	<b>Safety and prevention.....</b>	<b>6</b>
3.1	Introduction.....	6
3.2	Personnel training .....	6
<b>4</b>	<b>Technical description of the burner .....</b>	<b>7</b>
4.1	Burner designation .....	7
4.2	Models available.....	7
4.3	Burner categories - Countries of destination .....	7
4.4	Technical data .....	8
4.5	Electrical data.....	8
4.6	Maximum dimensions.....	9
4.7	Firing rates .....	10
4.8	Test boiler.....	10
4.9	Burner description .....	11
4.10	Electrical panel description.....	12
4.11	Burner equipment.....	12
4.12	Control box for the air/fuel ratio (LMV52...) .....	13
4.13	Servomotor (SQM48.4....) .....	15
<b>5</b>	<b>Installation .....</b>	<b>16</b>
5.1	Notes on safety for the installation .....	16
5.2	Handling .....	16
5.3	Preliminary checks .....	16
5.4	Operating position .....	17
5.5	Removal of the locking screws from the shutter.....	17
5.6	Preparing the boiler .....	17
5.6.1	Boring the boiler plate .....	17
5.6.2	Blast tube length.....	17
5.7	Securing the burner to the boiler .....	18
5.8	Access to head internal part.....	18
5.9	Nozzle installation .....	19
5.9.1	Recommended nozzle.....	19
5.10	Electrode position.....	20
5.11	Combustion head adjustment.....	20
5.12	Light oil supply.....	21
5.12.1	Double-pipe circuit.....	21
5.12.2	The loop circuit .....	21
5.12.3	Hydraulic connections .....	22
5.12.4	Hydraulic circuit diagram .....	22
5.12.5	Pressure variator .....	22
5.13	Pump .....	23
5.13.1	Technical data .....	23
5.13.2	Priming pump .....	23
5.14	Gas feeding .....	24
5.14.1	Gas feeding line .....	24
5.14.2	Gas train.....	25
5.14.3	Gas train installation .....	25

5.14.4	Gas pressure .....	25
5.14.5	Pilot - gas train connection.....	26
5.14.6	Ignition pilot burner .....	26
5.15	Activation of the burner lance .....	27
5.16	Electrical connections .....	28
5.16.1	Supply cables and external connections passage .....	28
5.17	Calibration of the thermal relay .....	29
<b>6</b>	<b>Start-up, calibration and operation of the burner .....</b>	<b>30</b>
6.1	Notes on safety for the first start-up .....	30
6.2	Adjustments prior to ignition (light oil) .....	30
6.2.1	Nozzle .....	30
6.2.2	Combustion head.....	30
6.2.3	Pump pressure.....	30
6.3	Burner ignition (light oil) .....	30
6.4	Adjustments prior to ignition (gas) .....	31
6.5	Burner start-up (gas) .....	31
6.6	Burner ignition.....	31
6.7	Change of fuel.....	31
6.8	Combustion air adjustment .....	32
6.8.1	Air / gas adjustment and output modulation.....	32
6.9	Pressure switch adjustment .....	33
6.9.1	Air pressure switch - check CO.....	33
6.9.2	Maximum gas pressure switch.....	33
6.9.3	Minimum gas pressure switch.....	33
6.9.4	PVP pressure switch kit .....	33
6.10	Final checks (with burner operating) .....	34
<b>7</b>	<b>Maintenance .....</b>	<b>35</b>
7.1	Notes on safety for the maintenance .....	35
7.2	Maintenance programme .....	35
7.2.1	Maintenance frequency.....	35
7.2.2	Checking and cleaning.....	35
7.3	Opening the burner .....	37
7.4	Closing the burner.....	37
<b>8</b>	<b>Faults - Possible causes - Solutions .....</b>	<b>38</b>
<b>A</b>	<b>Appendix - Accessories .....</b>	<b>39</b>
<b>B</b>	<b>Appendix - Electrical panel layout.....</b>	<b>41</b>

# 1 Declarations

## Declaration of conformity in accordance with ISO / IEC 17050-1

Manufacturer: RIELLO S.p.A.  
 Address: Via Pilade Riello, 7  
 37045 Legnago (VR)  
 Product: Dual fuel gas oil/ gas burners  
 Model: RLS 1000/EV MX  
 RLS 1200/EV MX

These products are in compliance with the following Technical Standards:  
 EN 676  
 EN 267  
 EN 12100  
 and according to the European Directives:

GAD	2009/142/EC	Gas Devices Directive
MD	2006/42/EC	Machine Directive
LVD	2014/35/UE	Low Voltage Directive
EMC	2014/30/UE	Electromagnetic Compatibility

Such products are marked as follows:



RLS 1000/EV MX	EC-0085CN0119	Class 2 (EN 267) - Class 3 (EN 676)
RLS 1200/EV MX	EC-0085CN0120	Class 2 (EN 267) - Class 3 (EN 676)

The quality is guaranteed by a quality and management system certified in accordance with UNI EN ISO 9001.

## Manufacturer's Declaration

RIELLO S.p.A. declares that the following products comply with the NOx emission limits specified by German standard "1. BImSchV revision 26.01.2010".

Product	Type	Model	Output
Dual fuel gas oil/ gas burners	1311 T2	RLS 1000/EV MX	1200 - 10600 kW
	1312 T2	RLS 1200/EV MX	1500 - 11500 kW

Legnago, 01.12.2015

Executive General Manager  
 RIELLO S.p.A. - Burner Department

Mr. U. Ferretti

Research & Development Director  
 RIELLO S.p.A. - Burner Department

Mr. F. Comencini

## 2 Information and general warnings

### 2.1 Information about the instruction manual

#### 2.1.1 Introduction

The instruction manual supplied with the burner:

- is an integral and essential part of the product and must not be separated from it; it must therefore be kept carefully for any necessary consultation and must accompany the burner even if it is transferred to another owner or user, or to another system. If the manual is lost or damaged, another copy must be requested from the Technical Assistance Service of the area;
- is designed for use by qualified personnel;
- offers important indications and instructions relating to the installation safety, start-up, use and maintenance of the burner.

#### Symbols used in the manual

In some parts of the manual you will see triangular DANGER signs. Pay great attention to these, as they indicate a situation of potential danger.

#### 2.1.2 General dangers

The **dangers** can be of **3 levels**, as indicated below.



Maximum danger level!  
This symbol indicates operations which, if not carried out correctly, cause serious injury, death or long-term health risks.



This symbol indicates operations which, if not carried out correctly, may cause serious injury, death or long-term health risks.



This symbol indicates operations which, if not carried out correctly, may cause damage to the machine and/or injury to people.

#### 2.1.3 Other symbols



**DANGER: LIVE COMPONENTS**  
This symbol indicates operations which, if not carried out correctly, lead to electric shocks with lethal consequences.



**DANGER: FLAMMABLE MATERIAL**  
This symbol indicates the presence of flammable materials.



**DANGER: BURNING**  
This symbol indicates the risks of burns due to high temperatures.



**DANGER: CRUSHING OF LIMBS**  
This symbol indicates the presence of moving parts: danger of crushing of limbs.



#### WARNING: MOVING PARTS

This symbol indicates that you must keep limbs away from moving mechanical parts; danger of crushing.



#### DANGER: EXPLOSION

This symbol signals places where an explosive atmosphere may be present. An explosive atmosphere is defined as a mixture - under atmospheric conditions - of air and flammable substances in the form of gases, vapours, mist or dust in which, after ignition has occurred, combustion spreads to the entire unburned mixture.



#### PERSONAL PROTECTION EQUIPMENT

These symbols indicate the equipment that must be worn and kept by the operator for protection against threats against safety and/or health while at work.



#### OBLIGATION TO ASSEMBLE THE HOOD AND ALL THE SAFETY AND PROTECTION DEVICES

This symbol signals the obligation to reassemble the hood and all the safety and protection devices of the burner after any maintenance, cleaning or checking operations.



#### ENVIRONMENTAL PROTECTION

This symbol gives indications for the use of the machine with respect for the environment.



#### IMPORTANT INFORMATION

This symbol indicates important information that you must bear in mind.



This symbol indicates a list.

#### Abbreviations used

Ch.	Chapter
Fig.	Figure
Page	Page
Sec.	Section
Tab.	Table

### 2.1.4 Delivery of the system and the instruction manual

When the system is delivered, it is important that:

- the instruction manual is delivered to the user by the system manufacturer, with the recommendation to keep it in the room where the heat generator is to be installed.
- The instruction manual shows:
  - the serial number of the burner;

- the address and telephone number of the nearest Assistance Centre.

- The system supplier must carefully inform the user about:
  - the use of the system;
  - any further tests that may be required before activating the system;
  - maintenance, and the need to have the system checked at least once a year by a representative of the manufacturer or another specialised technician.
 To ensure a periodic check, the manufacturer recommends the drawing up of a Maintenance Contract.

## 2.2 Guarantee and responsibility

The manufacturer guarantees its new products from the installation date, in accordance with the regulations in force and/or the sales contract. At the moment of the first start-up, check that the burner is integral and complete.



**WARNING**

Failure to observe the information given in this manual, operating negligence, incorrect installation and carrying out of non authorised modifications will result in the annulment by the manufacturer of the guarantee that it supplies with the burner.

In particular, the rights to the guarantee and the responsibility will no longer be valid, in the event of damage to things or injury to people, if such damage/injury was due to any of the following causes:

- incorrect installation, start-up, use and maintenance of the burner;
- improper, incorrect or unreasonable use of the burner;
- intervention of unqualified personnel;
- carrying out of unauthorised modifications on the equipment;
- use of the burner with safety devices that are faulty, incorrectly applied and/or not working;
- installation of untested supplementary components on the burner;
- powering of the burner with unsuitable fuels;
- faults in the fuel supply system;
- use of the burner even following an error and/or an irregularity;
- repairs and/or overhauls incorrectly carried out;
- modification of the combustion chamber with inserts that prevent the regular development of the structurally established flame;
- insufficient and inappropriate surveillance and care of those burner components most likely to be subject to wear and tear;
- the use of non-original components, including spare parts, kits, accessories and optional;
- force majeure.

**The manufacturer furthermore declines any and every responsibility for the failure to observe the contents of this manual.**

### 3 Safety and prevention

#### 3.1 Introduction

The burners have been designed and built in compliance with current regulations and directives, applying the known technical rules of safety and envisaging all the potential danger situations.

It is necessary, however, to bear in mind that the imprudent and clumsy use of the equipment may lead to situations of death risk for the user or third parties, as well as the damaging of the burner or other items. Inattention, thoughtlessness and excessive confidence often cause accidents; the same applies to tiredness and sleepiness.

It is a good idea to remember the following:

- The burner must only be used as expressly described. Any other use should be considered improper and therefore dangerous.

In particular:

it can be applied to boilers operating with water, steam, diathermic oil, and to other uses expressly named by the manufacturer;

the type and pressure of the fuel, the voltage and frequency of the electrical power supply, the minimum and maximum deliveries for which the burner has been regulated, the pressurisation of the combustion chamber, the dimensions of the combustion chamber and the room temperature must all be within the values indicated in the instruction manual.

- Modification of the burner to alter its performance and destinations is not allowed.
- The burner must be used in exemplary technical safety conditions. Any disturbances that could compromise safety must be quickly eliminated.
- Opening or tampering with the burner components is not allowed, apart from the parts requiring maintenance.
- Only those parts envisaged by the manufacturer can be replaced.



The manufacturer guarantees safety and proper functioning only if all burner components are intact and positioned correctly.

#### 3.2 Personnel training

The user is the person, body or company that has acquired the machine and intends to use it for the specific purpose. He is responsible for the machine and for the training of the people working around it.

The user:

- Undertakes to entrust the machine exclusively to suitably trained and qualified personnel;
- Undertakes to inform his personnel in a suitable way about the application and observance of the safety instructions. With that aim, he undertakes to ensure that everyone knows the use and safety instructions for his own duties;
- Personnel must observe all the danger and caution indications shown on the machine.
- Personnel must not carry out, on their own initiative, operations or interventions that are not within their province.
- Personnel must inform their superiors of every problem or dangerous situation that may arise.
- The assembly of parts of other makes, or any modifications, can alter the characteristics of the machine and hence compromise operating safety. The manufacturer therefore declines any and every responsibility for any damage that may be caused by the use of non-original parts.

In addition:




- the user must take all the measures necessary to prevent unauthorised people gaining access to the machine;
- the user must inform the manufacturer if faults or malfunctioning of the accident prevention systems are noticed, along with any presumed danger situation.
- personnel must always use the personal protective equipment envisaged by legislation and follow the indications given in this manual.



## 4 Technical description of the burner

### 4.1 Burner designation



### 4.2 Models available

Designation	Voltage	Start-up	Code
RLS 1000/EV MX TC	3/400/50	Direct/Inverter	20051416
RLS 1200/EV MX TC	3/400/50	Direct/Inverter	20047475

### 4.3 Burner categories - Countries of destination

Country of destination	Gas category
SE - FI - AT - GR - DK - ES - GB - IT - IE - PT - IS - CH - NO	I <sub>2</sub> H
DE	I <sub>2</sub> ELL
NL	I <sub>2</sub> L
FR	I <sub>2</sub> Er
BE	I <sub>2</sub> E(R)B
LU - PL	I <sub>2</sub> E

**4.4 Technical data**

Model			RLS 1000/EV MX	RLS 1200/EV MX
Type			1311 T2	1312 T2
Output <sup>(1)</sup>	min - max	kW	1200/3750 ÷ 10600	1500/5500 ÷ 11500
Delivery <sup>(1)</sup>		kg/h	100/315 ÷ 867	171/462 ÷ 942
Fuels			– Light oil, max. viscosity at 20 °C: 6 mm <sup>2</sup> /s (1.5 °E - 6 cSt) – Natural gas: G20 (methane gas) - G21 - G22 - G23 - G25	
Gas pressure at max. output <sup>(2)</sup> - Gas: G20/G25		mbar	67.8/101.1	97.2/145
Operation			– Continuous (min. 1 stop every 72 hours) – Modulating	
Nozzles		number	1	
Standard applications			Boilers: water, steam, diathermic oil	
Ambient temperature		°C	0 - 50	
Combustion air temperature		°C max	60	
Pump	Output at 30 bar	kg/h	1400	1826
	Pressure range	bar	9/40	9/40
	Fuel temperature	°C max	140	140
Noise levels <sup>(3)</sup>	Sound pressure	dB(A)	85,4	84,4
	Sound power		100,6	99,7
Weight		kg	500	540

**Tab. A**

<sup>(1)</sup> Reference conditions: Ambient temperature 20°C - Gas temperature 15°C - Barometric pressure 1013 mbar - Altitude 0 m a.s.l.

<sup>(2)</sup> Pressure on the test point 28)(Fig. 4) with zero pressure in the combustion chamber and at maximum burner output.

<sup>(3)</sup> Noise emission tests carried out as per Directive EN 15036-1, with measurement accuracy  $\delta \pm 1.5$  dB, in the manufacturer's combustion lab with burner operating on test boiler at maximum output.

**4.5 Electrical data**

Model			RLS 1000/EV MX		RLS 1200/EV MX
Electrical supply			3N ~ 400V 50 Hz		
Fan motor IE2	rpm		2935	2964	2920
	V		400/690	400/690	400/690
	kW		22	21	25
	A		38.6/22.3	41.8/24.2	44.1/25.5
Pump motor	rpm		1458		1400
	V		230/400		400
	kW		2,2		4
	A		9.3/5.4		8.2
Ignition transformer		V1 - V2 I1 - I2	230V - 1 x 8 kV 1A - 20mA		
Electrical power consumption	Light oil	kW max	26	25	31
	Gas		24	23	27
Protection level			IP 55		

**Tab. B**

Model		RLS 1000/EV MX		RLS 1200/EV MX	
Electrical supply		3N ~ 400V 50 Hz			
Fan motor IE3	rpm	2880	2880	2880	
	V	400/690	400/690	400/690	
	kW	22	21	25	
	A	38.1/22	38.2/22.3	43.4/25.1	
Pump motor	rpm	1458		1400	
	V	230/400		400	
	kW	2,2		4	
	A	9.3/5.4		8.2	
Ignition transformer	V1 - V2 I1 - I2	230 V - 1 x 8 kV 1 A - 20 mA			
Electrical power consumption	Light oil Gas	kW max	27 24	32 27.2	
Protection level		IP 55			

Tab. C

## 4.6 Maximum dimensions

The maximum dimensions of the burner are given in Fig. 1.  
Bear in mind that inspection of the combustion head requires the burner to be opened and the rear part turned on the hinge.

The maximum dimensions of the open burner are indicated by the L and R positions.

The I position is reference for the refractory thickness of the boiler door.




Fig. 1

mm	A	B	C	D	E	F	G	H	I	L	R
RLS 1000/EV MX	1637	674	200	413	885	DN80	1206	1338	484	1425	1350
RLS 1200/EV MX	1637	658	200	456	885	DN80	1250	1338	465	1425	1350

Tab. D

### 4.7 Firing rates

The **MAXIMUM OUTPUT** is chosen from within the continuous diagram area (Fig. 2).

The **MINIMUM OUTPUT** must not be lower than the minimum limit of the diagram:

RLS 1000/EV MX = 3750 kW

RLS 1200/EV MX = 5500 kW



The firing rate value (Fig. 2) has been obtained considering an ambient temperature of 20°C, an atmospheric pressure of 1013 mbar (approx. 0 m a.s.l.), and with the combustion head adjusted as shown on pag. 20.




Fig. 2

### 4.8 Test boiler

The burner/boiler combination does not pose any problems if the boiler is EC approved and its combustion chamber dimensions are similar to those indicated in the diagram (Fig. 3).

If the burner must be combined with a boiler that has not been EC approved and/or its combustion chamber dimensions are clearly smaller than those indicated in the diagram, consult the manufacturer.

The firing rates were set in relation to special test boilers, according to EN 676 regulations.

In Fig. 3 you can see the diameter and length of the test combustion chamber.

#### Example:

Output 7000 kW - diameter 120 cm - length 6 m.

#### MODULATING RATIO

The modulating ratio, obtained in the test boilers, according to standard (EN 676 for gas, EN 267 for light oil), is of 4:1




Fig. 3

## 4.9 Burner description




Fig. 4

- |    |   |    |   |
|----|---|----|---|
| 1  | Lifting rings   | 26 | Maximum oil pressure switch   |
| 2  | Fan   | 27 | Minimum oil pressure switch   |
| 3  | Fan motor   | 28 | Combustion head gas pressure test point   |
| 4  | Air damper servomotor                                     | 29 | Rpm probe   |
| 5  | Oil modulator   | 30 | 3-way valve for the mechanical activation of the burner lance   |
| 6  | Combustion head   | 31 | Locking screws of the shutter during the transport (replace them with the screws M12x25 supplied with the burner) |
| 7  | Ignition pilot  |    |   |
| 8  | Flame stability disk                                      |    |   |
| 9  | Electrical panel casing                                   |    |   |
| 10 | Hinge for opening the burner                              |    |   |
| 11 | Fan air inlet   |    |   |
| 12 | Pipe coupling   |    |   |
| 13 | Gasket for boiler fixing                                  |    |   |
| 14 | Nozzle return pressure gauge                              |    |   |
| 15 | Shutter   |    |   |
| 16 | Combustion head movement lever                            |    |   |
| 17 | Air damper movement lever                                 |    |   |
| 18 | Minimum air pressure switch (differential operating type) |    |   |
| 19 | Combustion head air pressure test point                   |    |   |
| 20 | Maximum gas pressure switch with pressure test point      |    |   |
| 21 | QRI cell  |    |   |
| 22 | Pressure test point for air pressure switch "+"           |    |   |
| 23 | Gas butterfly valve and oil modulator servomotor          |    |   |
| 24 | Pump  |    |   |
| 25 | Pump motor  |    |   |



CAUTION



WARNING

The burner can be opened to the right or to the left without links to the fuel supply side.

When the burner is closed, the hinge can be refitted on the opposite side.

The gas can only enter from the right side of the burner as shown in Fig. 4.

#### 4.10 Electrical panel description

- 1 Terminal board for O2 kit
- 2 Clean contacts output relay
- 3 Electronic cam transformer
- 4 Electronic control box
- 5 Ignition transformer
- 6 Shielding terminals
- 7 Stop push-button
- 8 Off-automatic selector
- 9 Light signalling of main fuel valve open
- 10 Fuel selector and enable signal to remote fuel selector
- 11 Light signalling of mains live state
- 12 Light signalling of fan motor lockout and pump motor
- 13 Light signalling of burner lockout and reset switch
- 14 Heat request signal
- 15 Pump motor contactor and thermal relay
- 16 Oil valve plug/socket/Pump motor/P G m (Deriv. unit)
- 17 AZL display
- 18 Main terminal supply board
- 19 Air pressure switch
- 20 Supply cables, external connections and kits
- 21 Auxiliary circuits fuse
- 22 Plug/socket servomotor
- 23 Flame sensor plug/sensor socket

#### NOTE

Two types of burner failure may occur:

- **Control box lockout:** if the control box pushbutton (**red led**) 13)(Fig. 5) lights up, it indicates that the burner is in lockout. release by pressing the pushbutton 13)(Fig. 5).
- **Motors lockout:** release by pressing the button on the relevant thermal relay.




fig. 5

#### 4.11 Burner equipment

Gasket for gas train flange	No. 1
Gas flange fixing screws, M 16 x 70	No. 8
Thermal insulation screen	No. 1
M 20 x 70 screws to secure the burner flange to the boiler	No. 4
Pressure switch (for leak detection control)	No. 1
Light gas flexible hoses	No. 2
Fitting 1" 1/2 - 3/4" (RLS 1200/EV MX)	No. 1
Fitting 3/4" - 1/2" (RLS 1200/EV MX)	No. 1
Rotating elbow 1/2" (RLS 1000/EV MX)	No. 1
Technical instructions.	No. 1
Spare parts list.	No. 1

## 4.12 Control box for the air/fuel ratio (LMV52...)

### Warnings



To avoid accidents, material or environmental damage, observe the following instructions!

The LMV52 control box... is a safety device! Avoid opening or modifying it, or forcing its operation. Riel-lo S.p.A. cannot assume any responsibility for damage resulting from unauthorised interventions!

#### Risk of explosion!

An incorrect configuration can provoke fuel over-charging, with the consequential risk of explosion! Operators must be aware that incorrect settings made on the AZL5... display and operating unit and incorrect settings of the fuel and / or air actuator positions can lead to dangerous burner operating conditions.

- All interventions (assembly and installation operations, assistance, etc.) must be carried out by qualified personnel.
- Before modifying the wiring in the LMV52 control box connection area, fully disconnect the system from the power supply (omnipolar separation). Check the system is not powered and cannot be accidentally reconnected. Failure to do this will lead to the risk of electrocution.
- Protection against electrocution from the LMV5... control box and all connected electric components is obtained with correct assembly.
- Before any intervention (assembly and installation operations, assistance, etc.), ensure the wiring is in order and that the parameters are correctly set, then make the safety checks.
- Falls and collisions can negatively affect the safety functions. In this case, the control box must not be operated, even if it displays no evident damage.
- In programming mode, the position check of actuators and VSD (checking electronic fuel / air ratio control) is different from the check during automatic operation.  
As for automatic operation, the actuators are guided together to the positions requested and, if an actuator does not reach the position requested, adjustments are made until the position is actually reached. However, in contrast to automatic operation, there are no time limits to these corrective actions.  
The other actuators maintain their positions until all actuators have reached the positions currently required.  
This is absolutely important to set the fuel / air ratio control system.  
During the time the fuel / air ratio curves are being programmed, the person making the plant settings must continuously monitor the quality of the combustion process (e.g. by means of a flue gas analyzer).  
Also, if combustion levels are poor, or in the event of dangerous situations, the commissioning engineer must take appropriate action (e.g. switching off manually).

To ensure the safety and reliability of the LMV5... system, the following instructions must also be followed:

- Avoid conditions that can favour the development of condensate and humidity. Otherwise, before switching on again, make sure that the entire control box is perfectly dry!
- Static charges must be avoided since they can damage the control box's electronic components when touched.



D9301

Fig. 6

### Mechanical structure

The LMV5... control box is a system to check the burners, based on a microprocessor and equipped with components to adjust and monitor medium and large capacity forced draught burners. The base control box of the LMV5... system incorporates the following components:

- Burner control with gas valve proving system
- Electronic fuel / air ratio control with a maximum of 4 (LMV51...) or 6 (LMV52...) actuators
- Optional PID temperature / pressure controller (load controller)
- Optional VSD module Mechanical design

### Installation notes

- Check the electric wiring inside the boiler complies with the national and local safety regulations.
- Do not confuse the powered conductors with the neutral ones.
- Make certain that strain relief of the connected cables is in compliance with the relevant standards (e.g. as per DIN EN 60730 and DIN EN 60335).
- Ensure that spliced wires cannot get into contact with neighboring terminals. Use adequate ferrules.
- Arrange the HV ignition cables separately, as far as possible from the control box and the other cables.
- The burner manufacturer must protect unused AC 230 V terminals with dummy plugs (refer to sections Suppliers of other accessory items).
- When wiring the unit, make sure that AC 230 V mains voltage cables are run strictly separate from extra low-voltage cables to avoid risks of electrical shock hazard.



**Electrical connection of ionization probe and flame detector**

It is important for signal transmission to be almost totally free of any disturbances or loss:

- always separate the detector cables from the other cables:
  - Line capacitance reduces the magnitude of the flame signal.
  - Use a separate cable.

- Respect the allowed cable lengths.
- The ionisation probe is not protected against the risk of electrocution. When connected to the electricity supply, the ionisation probe must be protected against any accidental contact.
- **Position the ignition electrode and the ionisation probe so that the ignition spark cannot form an arc on the probe (risk of electric overcharge).**

**Dati tecnici**

LMV52... base control box	Mains voltage	AC 230 V -15% / +10%
	Mains frequency	50 / 60 Hz $\pm 6$ %
	Power absorption	< 30W (normal)
	Safety class	I, with components in compliance with II and III, according to DIN EN 60730-1
Load on 'input' terminals	F1 unit fuse (internal)	6.3 AT
	Main fuse of perm. network (external)	Max. 16 AT
	Undervoltage	
	• Safety switch-off from operating position to mains voltage	< AC 186 V
	• Restart when mains voltage picks up	> AC 188 V
	Oil pump / magnetic clutch (nominal voltage)	
	• Nominal current	2A
	• Power factor	$\cos\phi > 0.4$
	Air pressure switch test valve (nominal voltage)	
	• Nominal current	0.5A
	• Power factor	$\cos\phi > 0.4$
Load on 'output' terminals	<b>Total load on the contacts:</b>	
	• Mains voltage	AC 230 V -15 % / +10 %
	• Total unit input current (safety circuit) load on contacts due to:	Max. 5 A
	- Fan motor contactor	
	- Ignition transformer	
	- Valve	
	- Oil pump / magnetic clutch	
	<b>Single contact loading:</b>	
	Fan motor contactor (nominal voltage)	
	• Nominal current	1A
	• Power factor	$\cos\phi > 0.4$
	Alarm output (nominal voltage)	
	• Nominal current	1A
	• Power factor	$\cos\phi > 0.4$
	Ignition transformer (nominal voltage)	
	• Nominal current	2A
	• Power factor	$\cos\phi > 0.2$
	Fuel gas valve (nominal voltage)	
	• Nominal current	2A
	• Power factor	$\cos\phi > 0.4$
	Fuel oil valve (nominal voltage)	
	• Nominal current	1A
	• Power factor	$\cos\phi > 0.4$
Cable lengths	Main line	Max. 100 m (100 pF/m)
Environmental conditions	Operation	DIN EN 60721-3-3
	Climatic conditions	Classe 3K3
	Mechanical conditions	Classe 3M3
	Temperature range	-20...+60°C
	Humidity	< 95% RH



## 4.13 Servomotor (SQM48.4....)

### Warnings



**To avoid accidents, material or environmental damage, observe the following instructions!**

**Avoid opening, modifying or forcing the actuators.**

- All interventions (assembly and installation operations, assistance, etc.) must be carried out by qualified personnel.
- Before modifying the wiring in the SQM4... system connection area, fully disconnect the burner control device from the power supply (omnipolar separation).
- To avoid the risk of electrocution, protect the connection terminals in a suitable manner and correctly fix the cover.
- Check the wiring is in order.
- Falls and collisions can negatively affect the safety functions. In this case, the unit must not be operated, even if it displays no evident damage.

### Assembly notes


- Check the relevant national safety standards are respected.
- The connection between the actuator command shaft and the control element must be rigid, without any mechanical play.
- To avoid an excessive load on the bearings due to rigid hubs, the use of compensation clutches without any mechanical play is recommended (e.g. metal bellows-type clutches).

### Installation notes

- Arrange the H.V. ignition cables separately, as far as possible from the control box and the other cables.
- To avoid the risk of electrocution, make sure that the 230V AC section of the SQM4... unit is fully separated from the functional low-voltage section.
- The static torque is reduced when the electrical supply of the actuator is switched off.
- The housing cover may only be removed for short periods of time for wiring or when making the addressing. In similar cases, make sure that dust or dirt does not penetrate inside the actuator.
- The actuator comprises a PCB with ESD-sensitive components.
- The top side of the board carries a cover which affords protection against direct contact. This protective cover must not be removed! The underside side of the board must not be touched.



**During the maintenance or replacement of the actuators, be careful not to invert the connectors.**



D8271

**Fig. 7**

### Dati tecnici

Operating voltage	AC 2 x 12 V via bus cable from the base unit or via a separate transformer
Safety class	extra low-voltage with safe isolation from mains voltage
Power consumption	26...34 VA
Degree of protection	to EN 60 529, IP 54, provided adequate cable entries are used
Cable connection	RAST3,5 connectors
Rotation direction	- Anticlockwise (standard) - Clockwise (inverted rotation)
Nominal torque (max)	20 Nm
Holding torque (max)	20 Nm
Running time (min.) for 90°	30 s.
Weight	approx. 1.6 kg
Environmental conditions:	
Operation	DIN EN 60 721-3-3
Climatic conditions	Classe 3K3
Mechanical conditions	Classe 3M3
Temperature range	-20...+60°C
Humidity	< 95% RH

**Tab. E**

## 5 Installation

### 5.1 Notes on safety for the installation

After carefully cleaning all around the area where the burner will be installed, and arranging the correct lighting of the environment, proceed with the installation operations.



All the installation, maintenance and disassembly operations must be carried out with the electricity supply disconnected.



The installation of the burner must be carried out by qualified personnel, as indicated in this manual and in compliance with the standards and regulations of the laws in force.



Combustion air inside the boiler must be free from hazardous mixes (e.g.: chloride, fluoride, halogen); if present, it is highly recommended to carry out cleaning and maintenance more frequently.

### 5.2 Handling

The packaging of the burner includes a wooden platform, so it is possible to move the burner (still packaged) with a transpallet truck or fork lift truck.



The handling operations for the burner can be highly dangerous if not carried out with the greatest attention: keep any unauthorised people at a distance; check the integrity and suitability of the available means of handling. Check also that the area in which you are working is empty and that there is an adequate escape area (i.e. a free, safe area to which you can quickly move if the burner should fall). When handling, keep the load at not more than 20-25 cm from the ground.



After positioning the burner near the installation point, correctly dispose of all residual packaging, separating the various types of material.



Before proceeding with the installation operations, carefully clean all around the area where the burner will be installed.

### 5.3 Preliminary checks

#### Checking the consignment



After removing all the packaging, check the integrity of the contents. In the event of doubt, do not use the burner; contact the supplier.



The packaging elements (wooden cage or cardboard box, nails, clips, plastic bags, etc.) must not be abandoned as they are potential sources of danger and pollution; they should be collected and disposed of in the appropriate places.

RBL		A		B		C	
D		E				F	
GAS-KASU		<input checked="" type="checkbox"/>		G		H	
GAZ-AERO				G		H	
I							
HEZ-FUE		L					
RELLOSpA I-37045 Legnaro (VR)				CE 0085			

D9243

Fig. 8

#### Checking the characteristics of the burner

Check the identification label of the burner, showing:

- the model (A)(Fig. 8) and type of burner (B);
  - the year of manufacture, in cryptographic form (C);
  - the serial number (D);
  - the data for electrical supply and the protection level (E);
  - the absorbed electrical power (F);
  - the types of gas used and the relative supply pressures (G);
  - the data of the burner's minimum and maximum output possibilities (H) (see Firing rate)
- Warning.** The burner output must be within the boiler's firing rate;
- the category of the appliance/countries of destination (I).
  - light oil maximum viscosity (L).



A burner label that has been tampered with, removed or is missing, along with anything else that prevents the definite identification of the burner and makes any installation or maintenance work difficult.

## 5.4 Operating position



- The burner is designed to operate only in positions 1, 2, 3 and 4 (Fig. 9).
- Installation 1 is preferable, as it is the only one that allows the maintenance operations as described in this manual.
- Installations 2, 3 and 4 permit operation but make maintenance and inspection of the combustion head more difficult.



- Any other position could compromise the correct operation of the appliance.
- Installation 5 is prohibited for safety reasons.




Fig. 9

## 5.5 Removal of the locking screws from the shutter

Remove the screws and the nuts 1) and 2)(Fig. 10), before installing the burner on the boiler. Replace them with the screws 3) M12x25 supplied with the burner.




Fig. 10

## 5.6 Preparing the boiler

### 5.6.1 Boring the boiler plate

Drill the combustion chamber locking plate as shown in Fig. 11. The position of the threaded holes can be marked using the thermal screen supplied with the burner.

### 5.6.2 Blast tube length

The length of the blast tube must be selected according to the indications provided by the manufacturer of the boiler, and in any case it must be greater than the thickness of the boiler door complete with its fettling.

For boilers with front flue passes 1)(Fig. 12) or flame inversion chamber, a protection in refractory material 5) must be inserted between the boiler fettling 2) and the blast tube 4).

This protective fettling must not compromise the extraction of the blast tube.

For boilers with a water-cooled frontpiece, a refractory lining 2)-5)(Fig. 12) is not necessary, unless expressly requested by the boiler manufacturer.




Fig. 11

mm	A	B	C
RLS 1000/EV MX	460	608	M 20
RLS 1200/EV MX	500	608	M 20

Tab. F

### 5.7 Securing the burner to the boiler




Prepare a suitable lifting system using rings 3) (Fig. 12).

- Insert the thermal protection supplied with the blast tube 4).
- Insert the entire burner on the boiler hole, previously fitted, as in Fig. 11, and fix it with the screws supplied.



**WARNING**

**The seal between burner and boiler must be airtight.**



**Fig. 12**


### 5.8 Access to head internal part

In order to reach inside the combustion head (Fig. 13) proceed as follows:

- disconnect the derivation unit socket 1) and the QRI photo-cell 2);
- disconnect the leverage of the head motor drive 3);
- remove the 4 fixing screws 4);
- open the burner on the hinge;
- disconnect the cable of the pilot electrode 5);
- release the ignition pilot fitting 6);
- remove the screw/gas pressure socket 7) of the head;
- disconnect the light oil pipes unscrewing the two pipe fittings 8);
- remove the oil lance lockout screw 9);
- release the oil lance from the combustion head 10);
- pull out the inner part of the head 11).



Be careful as some drops of fuel may leak out during this phase.



**Fig. 13**

## 5.9 Nozzle installation

The burner complies with the emission requirements of the EN 267 standard. In order to guarantee that emissions do not vary, recommended and/or alternative nozzles specified by Riello in the Instruction and warning booklet should be used.



**WARNING**

It is advisable to replace the nozzle once a year during periodical maintenance.



**CAUTION**

The use of nozzles other than those specified by Riello S.p.A. and inadequate regular maintenance may result into emission limits non-conforming to the values set forth by the regulations in force, and in extremely serious cases, into potential hazards to people and objects.

The manufacturing company shall not be liable for any such damage arising from nonobservance of the requirements contained in this manual.

Fit the nozzle with a 24 mm (for RLS 1000/EV MX) and 41 mm (for RLS 1200/EV MX), passing from the centre opening of the flame stability disc (Fig. 14).

Fit the nozzles with the fuel interception rod on the nozzle holder. To calibrate the delivery range of operation of the nozzle, adjust the fuel pressure on the nozzle return line, according to Tab. G.



**WARNING**

- Do not use any sealing products such as gaskets, sealing compound, or tape.
- Be careful to avoid damaging the nozzle sealing seat.
- The nozzle must be screwed into place tightly but not to the maximum torque value provided by the wrench.




Fig. 14

### 5.9.1 Recommended nozzle

Model	Nozzle	
RLS 1000/E MX	– Bergonzo	type B5 60°
	– Fluidics	type W2 60°
RLS 1200/E MX	– Bergonzo	type C3 - C5 60°

#### Complete range of nozzles:

- Bergonzo type B5 60°  
350 - 375 - 400 - 425 - 450 - 475 - 500 - 525 - 550 - 575 - 600  
650 - 700 - 750 - 800 - 850 - 900.
- Bergonzo type C3 - C5 60°  
700 - 800 - 900 - 1000 - 1100
- Fluidics type W2 60°:  
375 - 400 - 450 - 500 - 550 - 600 - 650 - 700 - 750.

Nozzle	kg/h	Delivery pressure bar	Return pressure (bar)	kg/h	kW
Bergonzo B5 60°	350	18	8	100	1200
		20	17.5	315	3750
	600	20	6	140	1675
		22	16	563	6700
	750	20	6.5	180	2150
		22	19	722	8600
	900	16	4	168	2000
		20	15	867	10300
Bergonzo C3 - C5 60°	700	18	3	172	2043
		20	16	462	5500
	700	18	3	172	2043
		20	19	635	7550
	900	17	5	237	2815
		18	17.5	791	9400
	1100	16	6	273	3242
		18	16.5	961	11425

Tab. G

5.10 Electrode position



Place the electrode on the ignition pilot observing the dimensions specified in Fig. 15.




Fig. 15

5.11 Combustion head adjustment

The air damper servomotor 4)(Fig. 4), beyond varying the air output according to the output demand, through a leverage varies the combustion head adjustment.

This system allows an optimum adjustment also at minimum firing rate. Similarly to servomotor rotation, it is possible to vary the opening of the combustion head moving the tie-rod on the holes (5-6-7-8-10)(Fig. 16).




Fig. 16

The selection of the hole to be used is determined based on the maximum output requested, as illustrated in Tab. H.

In the factory, the adjustment is adjusted for the maximum stroke (hole 10, Fig. 16).

Leverage hole		Output (kW)	
		From	A
RLS 1000	5	1200	3750
	5	3750	6700
	8	6700	8600
	8	8600	10600
RLS 1200	5	1500	5500
	5	5500	7500
	6	7500	9600
	10	9600	11500

Tab. H



The gas pipes leave the factory calibrated at notch 1.

The adjustment shown in Fig. 17 allows the gas pipes to be positioned in the best way for the application on which the burner is installed (e.g. boilers with flame inversion chamber).




Fig. 17

## 5.12 Light oil supply



Explosion danger due to fuel leaks in the presence of a flammable source.

Precautions: avoid knocking, attrition, sparks and heat.

Make sure that the fuel interception tap is closed before performing any operation on the burner.



**WARNING**

The fuel supply line must be installed by qualified personnel, in compliance with current standards and laws.

### 5.12.1 Double-pipe circuit

The burner is equipped with a self-priming pump which is capable of feeding itself within the limits listed in Tab. I.

#### Tank higher than burner A (Fig. 18)

Distance "P" must not exceed 10 meters in order to avoid straining the pump's seal; distance "V" must not exceed 4 meters in order to allow pump self-priming even when the tank is almost empty.

#### Tank lower than burner B (Fig. 18)

Pump depression values higher than 0.45 bar (35 cm Hg) must not be exceeded because at higher levels gas is released from the fuel, the pump starts making noise and its working life-span decreases.

It is good practice to ensure that the return and suction lines enter the burner from the same height; in this way it will be less probable that the suction line fails to prime or stops priming.


### 5.12.2 The loop circuit

A loop circuit consists of a loop of piping departing from and returning to the tank with an auxiliary pump that circulates the fuel under pressure. A branch connection from the loop feeds the burner.

This circuit is extremely useful whenever the burner pump does not succeed in self-priming because the tank distance and/or height difference are higher than the values listed in Tab. I.

± H [m]	RLS 1000/EV MX				RLS 1000/EV MX			
	Ø [mm]				Ø [mm]			
	20	22	24	27	22	24	27	36
4.0	26	45	73	138	19	33	65	300
3.0	22	39	63	120	16	28	55	260
2.0	18	33	53	102	13	23	45	220
1.0	15	26	44	84	10	18	38	185
0.5	13	23	39	75	9	16	33	165
0	11	20	34	66	7	13	30	145
-4.0	-	-	-	-	-	-	-	-
-3.0	-	-	-	12	-	-	-	30
-2.0	-	7	14	30	-	-	11	70
-1.0	7	14	24	48	-	9	20	108
-0.5	9	17	29	57	5	11	25	125
0	11	20	34	66	7	13	29	145

**Tab. I**



**Fig. 18**

Key (Fig. 18)

H = Pump/Foot valve height difference

L = Piping length

Ø = Inside pipe diameter

1 = Burner

2 = Pump

3 = Filter

4 = Manual on/off valve

5 = Suction line

6 = Foot valve

7 = Quick closing manual valve with remote control (Italy only)

8 = On/off solenoid valve (Italy only). See electrical layout. Connections to be carried out by the installer (SV).

9 = Return line

10 = Check valve (only Italy)



### 5.12.3 Hydraulic connections



CAUTION



WARNING

- Make sure that the flexible hoses to the pump supply and return line are installed correctly.

Follow the instructions below:

- Tighten the flexible hoses with the supplied gaskets.
- Take care that the hoses are not stretched or twisted during installation.
- Place the pipes so that they are not crushed or are in contact with hot parts of the boiler and so it is possible to open the burner.
- Finally, connect the other end of the flexible hoses to the suction and return pipes.

### 5.12.4 Hydraulic circuit diagram

Key (Fig. 19)

- 1 Pump suction
- 2 Pump return line and nozzle return line
- 3 Pump pressure regulator
- 4 Delivery safety valve
- 5 Delivery safety valve
- 6 Nozzle delivery line
- 7 Nozzle without interception rod
- 8 Nozzle return line
- 9 Pressure variator on nozzle return line
- 10 Pressure variator servomotor
- 11 Pressure switch on nozzle return line
- 12 Safety valve on nozzle return line
- 13 Safety valve on nozzle return line
- 14 Pressure switch on pump delivery line
- M Pressure gauges
- V Vacuum connection




Fig. 19

### OPERATION

#### Pre-purging phase:

valves 4), 5), 12) and 13) closed.

#### Ignition and operation phase:

valves 4), 4), 12) and 13) open.

**Stop:** All valves closed.

### 5.12.5 Pressure variator

The pressure variator (Fig. 20), incorporated in the oil circuit valve group, makes it possible to vary the pressure on the nozzle return line depending on the output required.

The pressure on the return line is adjusted by varying a section by means of the rotation of the servomotor 23)(Fig. 4), which also controls the gas butterfly valve at the same time.

- Regulator to 0° (maximum opening) = minimum pressure on nozzle return line.
- Regulator to 90° (minimum opening) = maximum pressure on nozzle return line.

The servomotor is controlled by the electronic cam 3) (Fig. 5); thanks to this device, it is possible to set different curves for oil and gas on the same servomotor (also for the air damper servomotor 4)(Fig. 4).

- When **adjusting the gas**, it is recommended to adjust the servomotor to about 90° to reduce leaks from the gas butterfly valve.
- When **adjusting the oil**, the adjustment is done based on the nozzle fitted and on the required degree of modulation; in a situation of minimum firing rate, a rotation of 20° can be enough.




Fig. 20

Key (Fig. 20)

- 1 Nozzle return pressure gauge
- 2 Position indicator (0 ÷ 90) of the pressure variator
- 3 Maximum oil pressure switch on return circuit



## 5.13 Pump

## 5.13.1 Technical data

Pump	RLS 1000/EV MX VBHRG	RLS 1200/EV MX VBHGRP
Min. delivery rate at 40 bar pressure	1160 kg/h	1660 kg/h
Delivery pressure range	9 - 40 bar	9 - 40 bar
Max. suction depression	0.6 bar	0.6 bar
Viscosity range	6 - 800 cSt	6 - 800 cSt
Max. light oil temperature	140°C	140°C
Max. suction and return pressure	5 bar	5 bar
Pressure calibration in the factory	22 bar	22 bar

Tab. J




Fig. 21

Key (Fig. 21)

- |                     |                        |
|---------------------|------------------------|
| 1 Suction line      | G 3/4" (RLS 1000/EV)   |
|                     | G 1" 1/2 (RLS 1200/EV) |
| 2 Return line       | G 1"                   |
| 3 Vacuum connection | G 1/4"                 |
| 4 Gauge connection  | G 1/4"                 |
| 5 Pressure adjuster |                        |

## 5.13.2 Priming pump



Before starting the burner, make sure that the tank return line is not clogged.

Obstructions in the line could cause the sealing organ located on the pump shaft to break.

- In order for self-priming to take place, the screw 4) on the pump (Fig. 21) must be loosened to bleed off the air contained in the suction line.
- Start the burner by closing the remote controls. As soon as the burner starts, check the direction of rotation of the fan blade.
- The pump can be considered to be primed when the light oil starts coming out of the screw 4).
- Close the burner and undo the screws 4).

The time required for this operation depends upon the diameter and length of the suction tubing.

If the pump fails to prime at first start-up and the burner locks out, wait approx. 15 seconds, reset the burner, and then repeat the start-up operation. And so on.

After 5 or 6 starting operations allow 2 or 3 minutes for the transformer to cool.

Do not illuminate the QRI cell or the burner will lock out; the burner should lock out anyway about 10 seconds after it starts.



The a.m. operation is possible because the pump is already full of fuel when it leaves the factory.

If the pump has been drained, fill it with fuel through the opening on the vacuumeter 4) (Fig. 21) prior to starting; otherwise, the pump will seize.

Whenever the length of the suction piping exceeds 20-30 meters, the supply line must be filled using a separate pump.

### 5.14 Gas feeding



Explosion danger due to fuel leaks in the presence of a flammable source.

Precautions: avoid knocking, attrition, sparks and heat.

Make sure that the fuel interception tap is closed before performing any operation on the burner.



**WARNING**


The fuel supply line must be installed by qualified personnel, in compliance with current standards and laws.

#### 5.14.1 Gas feeding line

Key (Fig. 22 - Fig. 23 - Fig. 24 - Fig. 25)


- 1 Gas input pipe
- 2 Manual valve
- 3 Vibration damping joint
- 4 Pressure gauge with pushbutton cock
- 5 Filter
- 6A Includes:
  - filter
  - working valve
  - safety valve
  - pressure adjuster
- 6B Includes
  - working valve
  - safety valve
  - pressure adjuster
- 6C Includes
  - safety valve
  - working valve
- 6D Includes:
  - safety valve
  - working valve
- 7 Minimum gas pressure switch
- 8 Leak detection control, provided as an accessory or integrated, based on the gas train code. In compliance with the EN 676 standard, the leak detection control is compulsory for burners with maximum outputs over 1200 kW.
- 9 Gasket, for "flanged" versions only
- 10 Pressure adjuster
- 11 Train-Burner adaptor, supplied separately
- P2 Upline pressure of valves/adjuster
- P3 Upstream pressure of the filter
- L Gas train, supplied separately
- L1 The responsibility of the installer

#### MBC "threaded"




**Fig. 22**

#### MBC "flanged"




**Fig. 23**

#### DMV "flanged or threaded"



**Fig. 24**

#### CB "flanged or threaded"



**Fig. 25**

### 5.14.2 Gas train

Approved according to standard EN 676 and provided separately from the burner.

To select the correct gas train model, refer to the supplied "Burner-gas train combination" manual.

### 5.14.3 Gas train installation



Disconnect the electrical power using the main system switch.



Check that there are no gas leaks.



Beware of train movements: danger of crushing of limbs.



Make sure that the gas train is properly installed by checking for any fuel leaks.



The operator must use appropriate tools for installation.

The gas train is prearranged to be connected to the burner by the flange 1) (Fig. 26).




Fig. 26

### 5.14.4 Gas pressure

The Tab. K indicates the pressure drop of the combustion head and the gas butterfly valve depending on the operating output of the burner.

	kW	1 Δp (mbar)		2 Δp (mbar)	
		G 20	G 25	G 20	G 25
RLS 1000/EV MX	3750	9.2	13.7	1.0	1.4
	4000	10.8	16.0	1.1	1.6
	4500	13.9	20.7	1.4	2.1
	5000	17.0	25.4	1.7	2.5
	5500	20.2	30.1	2.1	3.1
	6000	23.3	34.8	2.4	3.7
	6500	26.4	39.4	2.9	4.3
	7000	30.4	45.3	3.3	5.0
	7500	34.8	51.9	3.8	5.7
	8000	39.2	58.5	4.4	6.5
	8500	43.6	65.1	4.9	7.3
	9000	49.2	73.3	5.5	8.2
RLS 1200/EV MX	9500	55.0	82.0	6.1	9.2
	10000	60.8	90.7	6.8	10.1
	10600	67.8	101.1	7.6	11.4
	5500	23.1	34.5	2.1	3.1
	6000	27.9	41.6	2.4	3.7
	6500	32.6	48.7	2.9	4.3
	7000	37.4	55.7	3.3	5.0
	7500	42.1	62.8	3.8	5.7
	8000	48.3	72.1	4.4	6.5
	8500	54.5	81.3	4.9	7.3
	9000	60.7	90.6	5.5	8.2
	9500	67.0	99.8	6.1	9.2
	10000	74.3	110.8	6.8	10.2
	10500	81.9	122.2	7.5	11.2
	11000	89.6	133.6	8.2	12.3
	11500	97.2	145.0	9.0	13.4

Tab. K

The values shown in Tab. K refer to:

- Natural gas G 20 NCV 9.45 kWh/Sm<sup>3</sup> (8.2 Mcal/Sm<sup>3</sup>)
- Natural gas G 25 NCV 8.13 kWh/Sm<sup>3</sup> (7.0 Mcal/Sm<sup>3</sup>)

#### Column 1

Pressure loss at combustion head.

Gas pressure measured at test point 1)(Fig. 27), with:

- combustion chamber at 0 mbar;
- burner working at maximum modulating output;
- combustion head set as in pag. 20.

#### Column 2

Pressure loss at gas butterfly valve 2)(Fig. 27) with maximum opening: 90°.

Calculate the approximate output of the burner thus:

- subtract the combustion chamber pressure from the gas pressure measured at test point 1) (Fig. 27).
- Find, in the table Tab. K related to the burner concerned, the pressure value closest to the result of the subtraction.
- Read off the corresponding output on the left.

### Example RLS 1000/EV MX with natural gas G20:

Operation at maximum modulating output

Gas pressure at test point 1)(Fig. 27) = 44.2 mbar

Pressure in combustion chamber = 5 mbar

$44.2 - 5 = 39.2$  mbar

A pressure of 39.2 mbar, column 1, corresponds in Tab. K to an output of 8000 kW.

This value serves as a rough guide; the effective output must be measured at the gas meter.

To calculate the required gas pressure at test point 1) (Fig. 27), set the maximum modulating output required from the burner operation:

- find the nearest output value in the table Tab. K for the burner in question.
- read, on the right (column 1), the pressure at the test point 1) (Fig. 27).
- Add this value to the estimated pressure in the combustion chamber.

### Example RLS 1000/EV MX with natural gas G20:

Operation at maximum modulating output

Gas pressure at an output of 8000 kW = 39.2 mbar

Pressure in combustion chamber = 5 mbar

$39.2 + 5 = 44.2$  mbar

pressure required at test point 1)(Fig. 27).

### 5.14.5 Pilot - gas train connection

The burner is fitted with a dedicated gas train that is fixed to the pipe coupling.

- It should be connected to the main train downstream the filter or the pressure regulator (depending on configuration).



Supply pressure  $68 \div 500$  mbar

### 5.14.6 Ignition pilot burner

For proper operation, adjust gas pressure (measured at pressure test point 1) (Fig. 28) as follows:

Model	Gas	mbar	Sm <sup>3</sup> /h
RLS 1000/E MX	G20	1.5	12.3
	G31	1.4	3.2
RLS 1200/E MX	G20	40	14.3
	G31	30	7.1

Tab. L



Check pilot flame stability before starting up the main burner.

In the case of ignition problems check:

- correct positioning of the ignition electrode;
- the gas pressure, according to indications.





Fig. 27





Fig. 28

### 5.15 Activation of the burner lance

The burner is equipped with a spray lance for light oil.

Fig. 30 shows the 3-way valve used for the mechanical activation of the burner lance and the point at which the compressed air input A) must be connected.

It must operate at 6 - 7 bar.




Fig. 29




Fig. 30

### 5.16 Electrical connections

#### Notes on safety for the electrical wiring



- The electrical wiring must be carried out with the electrical supply disconnected.
- Electrical wiring must be made in accordance with the regulations currently in force in the country of destination and by qualified personnel. Refer to the wiring diagrams.
- The manufacturer declines all responsibility for modifications or connections different from those shown in the wiring diagrams
- Check that the electrical supply of the burner corresponds to that shown on the identification label and in this manual.
- The burner has been type-approved for continuous use.  
This means they should compulsorily be stopped at least once every 72 hours to enable the control box to perform checks of its own start-up efficiency. Normally, burner stopping is guaranteed by the boiler's thermostat/pressure switch.
- If this is not the case, a time switch should be fitted in series to TL to stop the burner at least once every 72 hours. Refer to the wiring diagrams.
- The electrical safety of the device is obtained only when it is correctly connected to an efficient earthing system, made according to current standards. It is necessary to check this fundamental safety requirement. In the event of doubt, have the electrical system checked by qualified personnel. Do not use the gas tubes as an earthing system for electrical devices.
- The electrical system must be suitable for the maximum power absorption of the device, as indicated on the label and in the manual, checking in particular that the section of the cables is suitable for that level of power absorption.
- For the main power supply of the device from the electricity mains:
  - do not use adapters, multiple sockets or extensions;
  - use a multiple pole switch with at least a 3 mm gap between the contacts (overvoltage category III), as envisaged by the present safety standards.
- Do not touch the device with wet or damp body parts and/or in bare feet.
- Do not pull the electric cables.

Before carrying out any maintenance, cleaning or checking operations:



Disconnect the electrical supply from the burner by means of the main system switch.




Close the fuel interception tap.



Avoid condensate, ice and water leaks from forming.

If the hood is still present, remove it and proceed with the electrical wiring according to the wiring diagrams.

Use flexible cables in compliance with the EN 60 335-1 standard.



**Fig. 31**

#### 5.16.1 Supply cables and external connections passage

All the cables to be connected to the burner should be passed through cable grommets, as shown in Fig. 31.

Key (Fig. 31)

- 1 Electrical supply
- 2 Minimum gas pressure switch
- 3 Pressure switch for VPS gas valve leak detection
- 4 Gas train
- 5 Consents/Safety
- 6 Available



After carrying out maintenance, cleaning or checking operations, reassemble the hood and all the safety and protection devices of the burner.

### 5.17 Calibration of the thermal relay

The thermal relay (Fig. 32) serves to avoid damage to the motor due to an excessive absorption increase or if a phase is missing. For calibration 2), refer to the table indicated in the electrical layout (electrical wiring in charge of the installer).

To reset, in case of an intervention of the thermal relay, press button "RESET" 1).

The button "STOP" 3) opens the NC contact (95-96) and stops the motor.


Insert a screwdriver in the window "TEST/TRIP" 4) and move it in the arrow direction (to the right) to carry out the thermal relay test.



**WARNING**

The automatic reset can be dangerous.

This operation is not foreseen in the burner operation.



**Fig. 32**

## 6 Start-up, calibration and operation of the burner

### 6.1 Notes on safety for the first start-up



The first start-up of the burner must be carried out by qualified personnel, as indicated in this manual and in compliance with the standards and regulations of the laws in force.



Check the correct working of the adjustment, command and safety devices.

### 6.2 Adjustments prior to ignition (light oil)



It is recommended to adjust first the light oil burner and then the gas burner.

Carry out the fuel change with burner off.

The optimum calibration of the burner requires an analysis of the flue gases at the boiler outlet and interventions on the following points.

#### 6.2.1 Nozzle

See information on pag. 19.

#### 6.2.2 Combustion head

The adjustment of the combustion head already carried out on pag. 20 need not be altered unless the 2nd stage delivery of the burner is changed.

#### 6.2.3 Pump pressure

In order to change pump pressure, act on screw 5) (Fig. 21). See information on pag. 19.

### 6.3 Burner ignition (light oil)

Position the selector 1)(Fig. 33) in “**AUTO**”.

Position the selector 2) in “**OIL**” to select light oil fuel.


When the limit thermostat (TL) is closed, the “**HEAT REQUEST**” 3) signal must be switched on.

At first ignition, there is a momentary drop in fuel pressure due to the filling of the nozzle piping. This lowering of the fuel pressure

can cause the burner to lockout and can sometimes give rise to pulsations.

Once the following adjustments have been made, the ignition of the burner must generate a noise similar to the noise generated during operation.

If a burner lockout occurs, refer to the “Release procedure” given in the equipment manual supplied.



**Fig. 33**



## 6.4 Adjustments prior to ignition (gas)

In addition, the following adjustments must also be made:

- Slowly open the manual valves situated upstream from the gas train.
- Adjust the minimum gas pressure switch (Fig. 37) to the start of the scale.
- Adjust the maximum gas pressure switch (Fig. 36) to the end of the scale.
- Adjust the air pressure switch (Fig. 35) to the start of the scale.
- Purge the air from the gas line.  
We recommend using a plastic tube routed outside the building and to purge air until gas is smelt.
- Fit a U-type pressure gauge or a differential pressure gauge (Fig. 34), with socket (+) on the gas pressure of the pipe coupling and (-) in the combustion chamber.  
The manometer readings are used to calculate MAX burner output.
- Connect two lamps or testers to the two gas line solenoids to check the exact moment in which voltage is supplied.  
This operation is unnecessary if each of the two solenoid valves is equipped with a pilot light that signals voltage passing through.



Before starting up the burner, it is good practice to adjust the gas train so that ignition takes place in conditions of maximum safety, i.e. with gas delivery at the minimum.




Fig. 34

## 6.5 Burner start-up (gas)

Close the remote controls and position the selector 1)(Fig. 33) to **"AUTO"**.

Position the selector 2) to **"GAS"** to select gas as fuel.

Make sure that the lights or testers connected to the solenoids, or the pilot lights on the solenoids themselves, indicate that no volt-

age is present. If voltage is present, stop the burner immediately and check the electrical connections.

When the limit thermostat (TL) closes, the **"CALL FOR HEAT"** 3) signal must come on. The burner will subsequently begin its starting cycle.

## 6.6 Burner ignition

The burner should light after having performed the above steps.

If the motor starts up, but the flame does not appear and the control box goes into lockout, reset it and wait for a new ignition attempt.

If ignition is still not achieved, it may be that gas is not reaching the combustion head within the safety time period of 3 seconds. In this case increase gas ignition delivery.

The arrival of gas at the sleeve is indicated by the U-type manometer (Fig. 34).

If further burner lockouts occur, refer to the "Release procedure" given in the equipment manual supplied.

Once the burner has fired, now proceed with global calibration operations.

## 6.7 Change of fuel

There are three options of change of fuel:

- 1 with the AZL device 4)(Fig. 33);
- 2 with selector 2);
- 3 with a remote selector connected to the main terminal board.

The AZL device sets the priority fuel; the display shows the selected fuel.

Positioning the selector 2)(Fig. 33) to **"EXT"** activates the remote selection of the fuel. In this position, if there is no remote selector, the display shows the priority fuel.

## 6.8 Combustion air adjustment

Fuel/combustion air synchronization is done with the relevant servomotors (air and gas) by logging a calibration curve by means of the electronic cam.

It is advisable, to reduce the loss and for a wide calibration field, to adjust the servomotors to the maximum of the output used, the nearest possible to the maximum opening (90°).

On the gas butterfly valve, fuel step according to the burner output required, with servomotor completely open, is carried out by the pressure stabilizer placed on the gas train.

The values indicated in Tab. M and Tab. N can be a reference for a good combustion calibration.

EN 676		Air excess		CO
		Max. output $\lambda \leq 1.2$	Max. output $\lambda \leq 1.3$	
GAS	Theoretical max. CO <sub>2</sub> 0 % O <sub>2</sub>	CO <sub>2</sub> % Calibration		mg/kWh
		$\lambda = 1.2$	$\lambda = 1.3$	
G 20	11.7	9.7	9	≤ 1000
G 25	11.5	9.5	8.8	≤ 1000
G 30	14.0	11.6	10.7	≤ 1000
G 31	13.7	11.4	10.5	≤ 1000

**Tab. M**

EN 267		Air excess		CO
		Max. output $\lambda \leq 1.2$	Min. output $\lambda \leq 1.3$	
Theoretical max. CO <sub>2</sub> 0 % O <sub>2</sub>		CO <sub>2</sub> % Calibration		mg/kWh
		$\lambda = 1.2$	$\lambda = 1.3$	
15.2		12.6	11.5	≤ 1000

**Tab. N**

### 6.8.1 Air / gas adjustment and output modulation

The air/gas adjustment and output modulation system with which the **RLS** range burners are equipped carries out a series of integrated functions in order to optimise burner functioning, both for single operation and together with other units (e.g. double furnace boiler or more than one generator in parallel).

The basic system functions control:

- 1 The dosage of the air and fuel through positioning using direct servocommands of the relevant valves eliminating the possible play in the calibration systems with mechanical cam lever mechanisms, used on traditional modulating burners.
- 2 The modulation of the burner output in accordance with the load required by the system, with maintenance of the pressure or temperature of the boiler at the operating values set.
- 3 The sequence (cascade adjustment) of more than one boiler through the suitable connection of the various units and the activation of the internal software of the individual systems (option).

Further interfaces and communication functions with computers, for remote control or integration in central supervision systems are available on the basis of the configuration of the system.



**WARNING**

The first start up and every further internal setting operation of the adjustment system or the expansion of the base functions require access by means of password and are to be carried out by service personnel who are especially trained for the internal programming of the instrument and the specific application created with this burner.

The first start-up and curve synchronization manual is supplied with the burner.

At request, the complete manual for the control and setting of all parameters is available.

## 6.9 Pressure switch adjustment

### 6.9.1 Air pressure switch - check CO

Adjust the air pressure switch after performing all other burner adjustments with the air pressure switch set to the start of the scale (Fig. 35).

With the burner working at MIN output, insert a combustion analyser in the stack, slowly close the suction inlet of the fan (for example, with a piece of cardboard) until the CO value does not exceed 100 ppm.

Slowly turn the appropriate knob clockwise until the burner goes into lockout.

Check the indication of the arrow pointing upwards on the graduated scale.

Turn the knob clockwise again, until the value shown on the graduated scale corresponds with the arrow pointing downwards, and so recovering the hysteresis of the pressure switch (shown by the white mark on a blue background, between the two arrows). Now check the correct start-up of the burner.

If the burner locks out again, turn the knob anti-clockwise a little bit more.




Fig. 35




Fig. 36




Fig. 37




Fig. 38

### 6.9.2 Maximum gas pressure switch

Adjust the maximum gas pressure switch after having performed all the other burner adjustments with the maximum gas pressure switch set at the end of the scale (Fig. 36).

With the burner operating at maximum output, lower the adjustment pressure by slowly turning the relative knob anticlockwise until the burner locks out.

Now turn the knob clockwise by 0,2 kPa (2 mbar) and repeat the start-up of the burner.

If the burner locks out again, turn the knob clockwise again by 0,1 kPa (1 mbar).

### 6.9.3 Minimum gas pressure switch

Adjust the minimum gas pressure switch after performing all the other burner adjustments with the pressure switch set to the start of the scale (Fig. 37).

With the burner operating at maximum output, increase adjustment pressure by slowly turning the relative knob clockwise until the burner stops.

Now turn the knob anticlockwise by 0,2 kPa (2 mbar) and repeat burner start-up to ensure it is uniform.

If the burner locks out again, turn the knob anti-clockwise again by 0,1 kPa (1 mbar).

### 6.9.4 PVP pressure switch kit

Adjust the pressure switch for the leak detection control (PVP kit) (Fig. 38) according to the instructions supplied with the kit.



1 kPa = 10 mbar

WARNING

### 6.10 Final checks (with burner operating)

<ul style="list-style-type: none"> <li>➤ Open the thermostat/pressure switch TL</li> <li>➤ Open the thermostat/pressure switch TS</li> </ul>	➡	The burner must stop
<ul style="list-style-type: none"> <li>➤ Turn the gas maximum pressure switch knob to the minimum end of scale position</li> <li>➤ Turn the air pressure switch to the maximum end of scale position.</li> </ul>	➡	The burner must stop in lockout
<ul style="list-style-type: none"> <li>➤ Turn off the burner and cut off the power.</li> <li>➤ Disconnect the minimum gas pressure switch connector.</li> </ul>	➡	The burner must not start
<ul style="list-style-type: none"> <li>➤ Disconnect the QRI cell wire.</li> </ul>	➡	The burner must stop in lockout due to ignition failure

Tab. O



Make sure that the mechanical locking systems on the various adjustment devices are fully tightened.

## 7 Maintenance

### 7.1 Notes on safety for the maintenance

The periodic maintenance is essential for the good operation, safety, yield and duration of the burner.

It allows you to reduce consumption and polluting emissions and to keep the product in a reliable state over time.



**DANGER**

The maintenance interventions and the calibration of the burner must only be carried out by qualified, authorised personnel, in accordance with the contents of this manual and in compliance with the standards and regulations of current laws.

Before carrying out any maintenance, cleaning or checking operations:



**DANGER**

Disconnect the electrical supply from the burner by means of the main system switch.



**DANGER**

Close the fuel interception tap.



Wait for the components in contact with heat sources to cool down completely.

### 7.2 Maintenance programme

#### 7.2.1 Maintenance frequency



The gas combustion system should be checked at least once a year by a representative of the manufacturer or another specialised technician.

#### 7.2.2 Checking and cleaning



The operator must use the required equipment during maintenance.

##### Combustion

Carry out an analysis of the combustion discharge gases. Significant differences with respect to the previous check indicate the points where more care should be exercised during maintenance.

##### Combustion head

Open the burner and make sure that all components of the combustion head are in good condition, not deformed by the high temperatures, free of impurities from the surroundings and correctly positioned.

##### Voltage on the QRI cell

Minimum value for correct operation: 3.5 Vdc (value on AZL display at about 50%).

If the value is lower, it could be due to:

- cell not positioned correctly
- low voltage (lower than 187 V)
- bad regulation of the burner

In order to measure, use a voltmeter with a 10 Vdc scale connected as in the diagram (Fig. 39).




Fig. 39

##### Burner

Clean the outside of the burner.

##### Fan

Check to make sure that no dust has accumulated inside the fan or on its blades, as this condition will cause a reduction in the air flow rate and provoke polluting combustion.

##### Boiler

Clean the boiler as indicated in its accompanying instructions in order to maintain all the original combustion characteristics intact, especially the flue gas temperature and combustion chamber pressure.

### GAS OIL OPERATION

##### Pump

The delivery pressure must comply with Tab. G, pag. 19.

The depression must be less than 0.45 bar.

Unusual noise must not be evident during pump operation.

If the pressure is found to be unstable or if the pump runs noisily, the flexible hose must be detached from the line filter and the fuel must be sucked from a tank located near the burner.

This measure permits the cause of the anomaly to be traced to either the suction piping or the pump.

If the problem lies in the suction line, check the filter is clean and that air is not entering the piping.

##### Filters (Fig. 40)

Check the filtering baskets on line 1) and at nozzle 2) present in the system.

Clean or replace if necessary.

If rust or other impurities are observed inside the pump, use a separate pump to lift any water and other impurities that may have deposited on the bottom of the tank.




Fig. 40

### Nozzles

It is advisable to replace nozzles once a year during periodical maintenance.

Do not clean the nozzle openings;

### Hoses

Check that these are in good conditions.

### Fuel tank

Approximately every 5 years, suck any water on the bottom of the tank using a separate pump.

### Combustion

If the combustion values found at the start of the intervention do not satisfy current standards or anyway indicate a poor state of combustion (consult the table below), contact the Technical Assistance Service for the necessary adjustments.

EN 267	Air excess		CO
	Max. output $\lambda \leq 1.2$	Min. output $\lambda \leq 1.3$	
Theoretical max. CO <sub>2</sub> 0 % O <sub>2</sub>	CO <sub>2</sub> % Calibration		mg/kWh
	$\lambda = 1.2$	$\lambda = 1.3$	
15.2	12.6	11.5	≤ 1000

Tab. P

## GAS OPERATION

### Gas leaks

Make sure that there are no gas leaks on the pipework between the gas meter and the burner.

### Gas filter

Change the gas filter when it is dirty.

### Combustion

If the combustion values found at the start of the intervention do not satisfy current standards or anyway indicate a poor state of combustion (consult the table below), contact the Technical Assistance Service for the necessary adjustments.

EN 676		Air excess		CO
		Max. output $\lambda \leq 1.2$	Max. output $\lambda \leq 1.3$	
GAS	Theoretical max. CO <sub>2</sub> 0 % O <sub>2</sub>	CO <sub>2</sub> % Calibration		mg/kWh
		$\lambda = 1.2$	$\lambda = 1.3$	
G 20	11.7	9.7	9	≤ 1000
G 25	11.5	9.5	8.8	≤ 1000
G 30	14.0	11.6	10.7	≤ 1000
G 31	13.7	11.4	10.5	≤ 1000

Tab. Q

### 7.3 Opening the burner



Disconnect the electrical supply from the burner by means of the main system switch.



Close the fuel interception tap.



Wait for the components in contact with heat sources to cool down completely.

- Remove the tie-rod 1)(Fig. 41) of the head movement lever, undoing the nut 2).
- Disconnect the socket 3) of the oil servomotor.
- Disconnect the socket 4) of the gas servomotor.
- Remove the screws 5).
- At this point, it is possible to open the burner on the hinge.




Fig. 41

### 7.4 Closing the burner

Refit following the steps described but in reverse order; refit all burner components as they were originally assembled.



After carrying out maintenance, cleaning or checking operations, reassemble the hood and all the safety and protection devices of the burner.

**8    Faults - Possible causes - Solutions**

If faults arise in ignition or operations, the burner performs a "safety stop", which is signalled by the red burner lockout LED.

The display visualises alternately the lockout code and the relative diagnostic. To reset the start-up conditions, refer to the "Reset procedure" indicated in the control box manual supplied.

When the burner starts again, the red LED goes out and the control box is reset.

**WARNING**

In the event of a burner lockout, more than two consecutive burner reset operations could cause damage to the installation. On the third lockout, contact the Aftersales Service.

**DANGER**

If further lockouts or burner faults occur, interventions must only be made by qualified, authorised personnel (as indicated in this manual, and in compliance with the laws and regulations currently in force).



**A Appendix - Accessories****Probe for checking temperature/pressure**

Parameter to be checked		Probe	
	Adjustment field	Type	Code
Temperature	- 100...+ 500°C	PT 100	3010110
Pressure	0...2.5 bar	Output probe 4....20 mA	3010213
	0...16 bar		3010214

**AZL Kit (display and operating unit) - (Russia only)**

Burner	Code
RLS 1000/EV MX RLS 1200/EV MX	3010469

**Pressure switch kit for leak detection control (supplied as standard)**

Burner	Code
RLS 1000/EV MX RLS 1200/EV MX	3010344

**Software interface kit**

Burner	Code
RLS 1000/EV MX RLS 1200/EV MX	3010388

**Kit O<sub>2</sub>**

Burner	Code
RLS 1000/EV MX RLS 1200/EV MX	20041584

**Inverter Kit**

Burner	Code
RLS 1000/EV MX	3010468
RLS 1200/EV MX	3010447

**Soundproofing box kit**

Burner	Code
RLS 1000/EV MX RLS 1200/EV MX	3010401

**Flue gases sensor bracket kit**

Burner	Code
RLS 1000/EV MX RLS 1200/EV MX	20041585

**Air/combustion fume temperature sensor**

Parameter to be checked		Probe	
	Adjustment field	Type	Code
Temperature	- 100...+ 500°C	PT 1000Ni1000	3010377

**Gas trains in compliance with EN 676**


Please refer to manual.


**B Appendix - Electrical panel layout**


<b>1</b>	<b>Index of layouts</b>
<b>2</b>	Indication of references
<b>3</b>	Single-wire output layout
<b>4</b>	Fuel selection functional layout
<b>5</b>	LMV52.... functional layout
<b>6</b>	LMV52.... functional layout
<b>7</b>	LMV52.... functional layout
<b>8</b>	LMV52.... functional layout
<b>9</b>	LMV52.... functional layout
<b>10</b>	LMV52.... functional layout
<b>11</b>	LMV52.... functional layout
<b>12</b>	PLL52../QGO20.. functional layout
<b>13</b>	Electrical connection set by installer
<b>14</b>	Electrical connection set by installer
<b>15</b>	PLL52../QGO20.. functional layout


**2 Indication of references**

Sheet no. /1.A1  
 Coordinates
















Sheet : 7


SCHEMA FONCTIONNEL LMV52...

BETRIEBSSCHHEMA LMV52...


LMV52... OPERATIONAL LAYOUT


SCHEMA FUNZIONALE LMV52...







Sheet : 9


















## Wiring layout key

A5	Control box	VR1	Light oil return valve
A6	Module PLL	VS	Safety light oil valve
AZL	Display for control box	VU	Nozzle valve
BA	Output probe in current	XAZL	AZL display connector
BA1	Output device in current to modify remote setpoint	XAUX	Auxiliary terminal board
BA2	Load indicator at current input	XGD	Derivation unit connector
BA3	Device with current output for remote modulation	XPGM	Maximum gas pressure switch connector
BP	Pressure probe	XPO	Oil pressure switch connector
BP1	Pressure probe	XPO1	Oil return pressure switch connector
BT3	Probe Pt100, 3 wires	XS	Flame sensor connector
BT4	Probe Pt100, 3 wires	XSM	Servomotor connector
BT5	PT 1000 probe, 2 wires	X1	Main terminal supply board
BV	Output probe in voltage	X4	Derivation unit terminal board
BV1	Output device in voltage to modify remote setpoint	X02	Kit O <sub>2</sub> terminal strip
BV2	Device with voltage current output for remote modulation	X70	RPM sensor terminal board
F1	Fuse for inverter line	XVPI	Pilot valve 1 connector
F2	Pump motor thermal relay	XVPS	Pilot valve 2 connector
F3	Auxiliary fuse	Y	Gas adjustment valve + gas safety valve
F4	Three-phase line fuse		
GF	Inverter		
G2	Rpm sensor		
G10	Oxygen sensor		
G20	Fuel temperature probe		
G30	Air temperature probe		
H1	Light signalling burner on		
H2	Light signalling fan motor lockout and pump motor		
H3	Heat request lighting signal		
H4	Fuel delivery lighting signal		
KMP	Pump motor contact maker		
K1	Clean contacts output relay with fan motor working		
K2	Clean contacts output relay overload		
K3	Clean contacts output relay burner lockout		
K4	Clean contacts output relay for light oil operation		
K5	Clean contacts output relay for gas operation		
K8	Clean contacts output relay for gas burner switched on		
K9	Clean contacts output relay for light oil burner switched on		
MP	Pump motor		
MV	Fan motor		
PA	Air pressure switch		
PE	Burner earth		
PGMAX	Maximum gas pressure switch		
PGMin	Minimum gas pressure switch		
PGVP	Pilot valves gas pressure switch		
PO	Oil pressure switch		
PO1	Maximum oil pressure switch on return line		
Q1	Inverter power supply disconnect switch		
Q2	Line disconnect switch		
QRI	Flame sensor		
RS	Remote burner reset button		
S1	Emergency stop button		
S2	0 / AUTO selector		
S5	Fuel selector and enable signal to remote fuel selector		
SH3	Burner reset button and lock-out signal		
SM1	Servomotor		
SM2	Fuel servomotor		
SV	Remote safety light oil valve		
TA	Ignition transformer		
TL	Limit thermostat/pressure switch		
TS	Safety thermostat/pressure switch		
T1	Control box transformer		
VF	Light oil operation valve		
VP1	Pilot valve 1		
VP2	Pilot valve 2		
VR	Light oil return valve		

---

The logo consists of the word "RIELLO" in a bold, red, sans-serif typeface.

RIELLO S.p.A.  
I-37045 Legnago (VR)  
Tel.: +39.0442.630111  
[http:// www.riello.it](http://www.riello.it)  
[http:// www.riello.com](http://www.riello.com)